

Air Cooled Condenser Users Group: Corrosion Product Transport Monitoring



Daniel C. Sampson

Senior Technical Consultant – Power, Water, Wastewater

Sept 19-20, 2011 * San Francisco, CA

Disclaimer

This report was prepared by an employee of WorleyParsons (hereinafter called the Company) for oral presentation to the Air Cooled Condenser Users Group (hereinafter called the Society).

Neither the Society nor the Company, nor others involved in the preparation or review of this report, nor any of their employees, members, or persons acting on their behalf, makes any warranty, expressed or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed or referred to in this report, or represents that any use thereof would not infringe privately owned rights.

Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the Society, the Company, or others involved in the preparation or review of this report, or agency thereof. The views and opinions of the authors, contributors, and reviewers of the report expressed herein do not necessarily reflect those of the Society, the Company, or others involved in the preparation or review of this report, or any agency thereof.

This material is presented in furtherance of the Society's intention of serving the exchange of technical information as well as for identifying and resolving technical issues having to do with air-cooled condensers. If this material is provided as handout papers or in electronic form, it is intended for private use by individuals associated with work involving air cooled condensers, and is not intended for wide-scale duplication, publication and/or commercial distribution, except with approval by the original author(s).

Topics

- Why Monitor Corrosion Product Transport?
- Creating a Monitoring Program
- Sampling and Sample Methods
- Iron Monitoring Methods
- Costs and Time Commitments



Why Monitor Corrosion Product Transport?

- Protects people
 - Minimizes equipment failures and hazards
- Protects plant equipment
 - FIRST line of defense in problem detection
 - Protects ACC, feedwater, HRSGs and turbines
 - Predicts and minimizes cleaning needs and frequency
- Allows performance monitoring of the steam-condensate-feedwater cycle
 - Provide data to operating & chemistry personnel for detection of any deviations from control specs.
 - Allows corrective action




Boiler chemical cleaning tank farm

Creating a Monitoring Program

- Sample Locations and Limits
- Sample Frequency
- Interpreting Data
- Recommended Tests



Creating a Monitoring Program: Sample Locations and Limits



Creating a Monitoring Program: Frequency


- Normal Operation
 - Daily (to start) – all locations (include RACs if equipped)
 - Adjust schedule based on results
- Startup and Shutdown Profiles
 - Specific schedule important
 - Sample every 15 minutes for first 6 hours (or until levels stabilize)
 - Perform quarterly and after major maintenance
 - Determines “crud burst” duration and magnitude



Creating a Monitoring Program: Interpreting Data

Interpret data carefully


- Most transport occurs during transients
- S/U and S/D important



Particle index (discussed later) and ORP on plant startup

Creating a Monitoring Program: Recommended Tests

- Total, Soluble, and Filtered Tests to start
- Continue for 30-60 data sets (60 preferred)
- Analyze for consistency and trends
- Soluble test frequency decreases to monthly if results consistently non-detect
- Total (wet test) frequency to weekly if consistent with filtered results



Sampling and Sample Methods

- Continuously running
- SS lines, 1/4 to 3/8-inch
- Minimize line lengths
 - Minimizes lag time
 - Minimizes iron loss (through sample line deposition)
- Cooled to $< 90^{\circ}\text{F}$
- Flow rate 4-6 FPS
- Isokinetic samples best, but most plants don't have them (continuous flow especially important)



Sampling and Sample Methods

- Key Monitoring Parameters
 - pH
 - Total Iron (wet test)
 - Soluble Iron (wet test)
 - Suspended Iron (Millipore filter test)
 - Dissolved Oxygen
 - Treatment Chemical (oxygen scavenger, if used)
- Influencing Parameters
 - Na leakage from demineralizers and polishers
 - Alkalinity (CO₂ source) and TOC
 - Cation and Specific Conductivity of feedwater, condensate and steam
 - NH₃ and dissolved CO₂
 - Silica
 - Hardness
 - Na and hydrogen in the steam
 - Flow rates, temperatures and pressures


Iron Monitoring Methods

Method	Soluble Iron	Total Iron	Digestion Required	Test Type	Detection Limit (ppb)
TNTplus		X	X	Grab / Wet	200
FerroVer		X	X	Grab / Wet	20
TPTZ		X	X	Grab / Wet	10
1-10, Phenanthroline	X			Grab / Wet	20
FerroZine		X	X	Grab / Wet	10
TitraVer		X		Grab / Titration	10,000
FerroMo		X	X	Grab / Wet	10
Test Strips	X			Grab / Strips	150
Millipore (Suspended Iron)		X		Grab / Filter	10*
Composite Sampler		X		Composite / Filter	1
Off-site Lab	X	X		Grab / Off-site Lab	3
Particle Analysis		X		Continuous / Online	N/A (Particle Index)
Deposit Weight Density		X		Destructive	N/A

*Can lower detection limit with larger sample

Iron Monitoring Methods – Wet Tests


- Hach tests shown (typical)
- Specialty chemical suppliers may have their own
- Detection limit usually too high (minimum is 10 ppb)
- Require digestion (complicated and time consuming)
- Requires spectrophotometer
- Suspended iron test is better, but early testing should include wet tests



Iron Monitoring Methods – Suspended Iron

- Millipore filter test (filter through 0.45 micron filter)
- More accurate than wet tests
 - Wet test methods don't accurately measure total iron in drums
 - Iron changes form and does not show up on the traditional wet tests unless digested
- Uses B&W comparison chart
- Detection limit of 10 ppb for 1L sample
- Lower detection limit by increasing sample size
- 5L sample lowers detection limit to 2 ppb
- Manual filtering of 5L of sample impossible
 - Use a vacuum pump and filter assembly to accomplish this task


Iron Monitoring Methods – Suspended Iron



Iron Monitoring Methods – Suspended Iron



5L Sample Reservoir



Filter Assembly and 5L
Receiver



Vacuum Pump

Iron Monitoring Methods – Composite Sampling

- Millipore test uses visual comparison
- Composite sampling uses same filter, but off-site analysis provides greater accuracy
- Known volume of water passes through filter
- Corrosion products accumulate
- Filter removed and weighed after exposure
- Weight of iron (in mg) divided by total flow (in L) to provide result in mg/L or ug/L
- Additional analyses (like X-ray diffraction) can provide data on oxide composition

Iron Monitoring Methods – Composite Sampling



Iron Monitoring Methods – Off-site Lab

- Field test accuracy not the best (high detection limits)
- Off-site samples confirm field test results
- Should be obtained quarterly for all streams of interest (see diagram)
- Include soluble and total iron
- Samples must be preserved to ensure accuracy
- Pull samples when field grab samples are pulled
- Compare results to confirm accuracy
- Costly (\$250-\$400 per sample)

Iron Monitoring Methods – Particle Analysis

- Traditional monitoring of metal transport and generation in the steam cycle relies primarily on periodic wet tests
- Wet tests valuable, but leave significant holes in the data stream
- Every thermal, chemical, or hydraulic event liberates or generates metal oxides in the steam cycle
- These events occur often and cannot be scheduled - they occur as the plant operates

Iron Monitoring Methods – Particle Analysis

- Time-based testing (iron sampling at a specific frequency) important, but it cannot detect the majority of these events
- Particle analysis provides a window into metal liberation and transport as it occurs
- Two different technologies that can be used - particle size analysis and particle counts






Iron Monitoring Methods – Particle Analysis – Particle Counter or Particle Monitor


- PC reports counts in different size ranges
 - Requires 4 DCS inputs for each sample
 - Provides more data than PM, but requires more storage and data infrastructure
- PM provides only one reading – “index”
 - Only 1 DCS input/PI tag per sample
 - Index represents the total surface area of all particles passing through the sensor

Iron Monitoring Methods – Particle Analysis – Particle Counter or Particle Monitor


- Both may be useful
- Testing indicates that the majority of iron transport occurs as particles < 5 microns in size
- Most iron transport occurs as particles of similar and smaller size



Iron Monitoring Methods – Particle Analysis – Particle Counter or Particle Monitor





Condensate After Chemical Feed Particle Distribution



LP Economizer Outlet Particle Distribution

Iron Monitoring Methods – Particle Analysis – Particle Counter or Particle Monitor






Iron Monitoring Methods: Deposit Weight Density (DWD)

- Measures the amount of deposit on both the hot and cold side of a boiler tube.
 - NACE TM0199-99: Bead Blasting Method
 - Mechanical method, so follow B&W Cleaning Guidelines
- Sample from high heat release zone
 - Conventional unit: water wall approximately the centerline of the highest burner elevation
 - HRSG: HP evaporator, first row
- Used to determine need to clean boiler
 - Need to clean will be unit specific, as heat release and circulation play an important role in deposition on , and cooling of, the boiler tubes

Iron Monitoring Methods: Deposit Weight Density (DWD)

DWD tube
Sample
(before
cleaning)

- Weigh each side
- Clean
- Reweigh each side
- Difference is DWD



Iron Monitoring Methods: Deposit Weight Density - Chemical Cleaning Guidelines

US Units		Metric Units	
psi	g/ft ²	Bar	g/dm ²
< 1000	10 – 40	< 70	2.1 – 4.3
1000 – 2000	12 – 20	70 – 140	1.3 – 2.2
> 2000	10 - 12	> 140	1.1 – 1.3

- Follows B&W Guidelines
- Based on mechanical cleaning (bead blasting or scraping)
- Need to clean will be unit specific.



Iron Monitoring Methods – Using the Tools

- Conventional testing and DWD provide quantification
- Particle analysis technology provides visibility to previously undetectable events.
- The two approaches can be used to correlate particle index to metal transport (iron) test results
- Combining particle counts with wet test results "closes the loop" on steam cycle metal transport. The combination offers three windows into the process
 - Wet tests correlate particle index to iron transport
 - Particle index provides real-time, continuous indication of amount of iron moving through the system
 - DWD confirms amount of deposition on tubes

Costs and Time Commitments (Approximate)

Method	Cost (per test)	Cost (initial setup)	Time Required	Notes
Wet Tests	\$1.00	\$0 (assumes existing spectrophotometer and glassware)	Approximately 1 hour per day (concurrent with other sampling)	3 minutes per test, but 3-5 tests per day (condensate, FW, drums)
Millipore Filtered Iron Test	\$0.40-\$0.50	\$1,500 (Reservoir, vacuum pump, tubing, filter, etc.)	Approximately 2 hours per day (concurrent with other sampling)	Operators fill reservoir with sample, start vacuum pump, read result later
Off-site Lab	\$250-\$400	\$0	Approximately 4 hours per quarter	Performed quarterly and only on select samples
Particle Analysis	\$0	\$15,000	None – online analyzer with input to DCS	Assumes 2 particle monitors, 2 sample streams to each
Deposit Weight Density	\$15,000 every 3 years	\$0	Approximately 2 days every 3 years	Includes cost to cut and reweld sample.

Questions?

Daniel C. Sampson

Senior Consultant

Power/Water/Wastewater, WorleyParsons

707-643-2834 (office)

925-570-0842 (mobile)

dan.sampson@worleyparsons.com



What a good iron monitoring
program can prevent