




ACCUG:
Corrosion and
Cycle Chemistry

Fossil, Combined Cycle/HRSG and Industrial Plants
Review of History over Last 20 Years




Barry Dooley

ACCUG 2024
23rd and 24th July 2024
London, UK



1

ACC Come in Many Sizes






But the FAC / Corrosion damage is the same worldwide with all chemistries and plant types (Based on assessment/inspection work conducted in Australia, Canada, Chile, China, Cote d'Ivoire, Dubai, India, Ireland, Mexico, Qatar, Abu Dhabi, South Africa, Trinidad, UK and US)

2

Corrosion/FAC in ACC has Serious Consequences



- **High concentrations of iron around the cycle**
 - **Boiler/HRSG deposits** (expensive chemical cleaning)
 - **Boiler/HRSG Tube Failures** (overheating and UDC / HD*)
 - **Steam Turbine Deposits** (including aluminum)
- **Need for Iron Removal Processes**
 - **Condensate Polishing and/or Filters**
- **Limitations around the cycle**
 - **Condensate polishing** (may have to change mode to AFO*)
- **Overall an ACC “controls” the unit cycle chemistry**
 - **International Guidelines now available for ACC and two-phase flow** (IAPWS Volatile and FFS Guidance)



* UDC / HD – Under-deposit corrosion / hydrogen damage.
* AFO – Ammonium form operation

3


A Wide Variety of ACC Corrosion on Inspection


4




Discussion Items for ACCUG 2024



Reminder of ACC Damage & How Normally Addressed
DHACI provides uniformity for Inspections Worldwide
Introduction of Film Forming Substances (FFS)
International Experiences & Missing Information



July 2024




5

There is an ACC Corrosion Index to Categorize Corrosion and Track Improvements

DHACI

(Dooley, Howell, Air-cooled Condenser, Corrosion Index)




Air Cooled Condenser Users Group

6

DHACI for Tube Entries

1. Tube entries in relatively good shape (maybe some dark deposited areas)
2. Various black/grey deposits on tube entries as well as flash rust areas, but no white bare metal areas
3. Few white bare metal areas on a number of tube entries. Some black areas of deposit
4. Serious white bare metal areas on/at numerous tube entries. Lots of black areas of deposition adjacent to white areas
5. **Most serious. Holes in the tubing or welding. Obvious corrosion on many tube entries**


Examples included on slides

Dooley & Howell et al, PPChem 2009



7

DHACI for Steam Transport Ducts

- A. Ducting shows no general signs of two-phase damage
- B. Minor white areas on generally grey ducting. Maybe some tiger striping with darker grey/black areas of two-phase damage
- C. **Serious white bare metal areas in the hot box and at numerous changes of direction (eg. at intersections of exhaust ducting to vertical riser). White areas are obvious regions of lost metal.**

Dooley & Howell et al, PPChem 2009


8




ACC Users Group
Air Cooled Condenser Users Group
<http://acc-usersgroup.org/>
ACC.01
 Original Issue: May 12, 2015
 Revision due: May 12, 2018

Guideline for Internal Inspection of Air-Cooled Condensers

9


Inspections Worldwide show the same Features
 Combined Cycle with ACC after ~ 15,000 hrs, pH 9.1.



Concentration of two-phase FAC at tube entries beneath supports

10

Inspections Worldwide show the same Features
 750 MW Supercritical on OT at pH 9, ~4,000 hrs.



Concentration of two-phase FAC at tube entries beneath supports

11


Damage takes time to Arrest (after 2 Years with pH 9.8)



Cross member LDI not quickly "arrested" by pH

DHACI 4 **DHACI 2**


12




13




14




15




16




17




18




19




20



21



22




23

Achievable Total Fe (& Cu) Levels Different Plant Types/Optimized Chemistry Steady/Base Loaded


Feedwater		
OT:	Total Fe =	< 1 µg/kg
AVT:	Total Fe =	< 2 µg/kg
AVT (Mixed):	Total Fe & Cu =	< 2 µg/kg
HP/LP Heater Drains:	Total Fe & Cu =	< 1 µg/kg
HRSG Evaporators/Drums		
AVT/PT/CT:	Total Fe =	< 5 µg/kg
Units with Air-Cooled Condenser (ACC)		
ACC Outlet:	Total Fe =	< 10 µg/kg
Post Condensate Filter:	Total Fe =	< 5 µg/kg
Cogeneration / Industrial Plants		
Condensate Return:	Total Fe =	< 10 µg/kg

IAPWS TGD 6-13, September 2014


24




25



26





27




28


Please do not add FFS if your HP Evaporator looks like this
 (use the IAPWS Deposit Map to make an assessment)

2023 Assessment
 Total Loading ~65 mg/cm²





IAPWS Deposit Map




29

Beware of Increasing HP Evaporator Deposits after FFS Application
 (without detailed up-front review)


2018 Assessment
 2003 - 2015 AVT(R) and PT
 2015 - 2018 AVT(O) and PT
 Total Loading 19 - 24 mg/cm²

2022 Assessment
 2015 - 2020 AVT(O) and PT
 2020 - 2022 AVT(O) + FFP
 Total Loading 47 - 71 mg/cm²





30


HP Evaporator Heavy Deposits and Failure
 Double Pressure HRSG (9 and 0.5 MPa). HTF after FFAP Application without thorough upfront review (such as IAPWS Section 8)



Severe Under-deposit Corrosion in typical multi-laminated morphology

SLIDE 11



31

Some Final Thoughts on “corrosion” in ACC
 (Based on work conducted in Australia, Canada, Chile, China, Cote d'Ivoire, Dubai, India, Ireland, Mexico, Qatar, Abu Dhabi, South Africa, Trinidad, UK and US)

Increasing condensate pH to 9.8 will gradually eliminate the FAC damage at the tube entries and iron levels will reduce to international suggested levels (5 - 10 ppb) at CPD. Documented by a reducing DHACI. FFS will also work but not sufficient detailed documentation of ACC before and after application and currently no understanding of/for improvement using the wide range of FFS.

Damage on cross members is not “arrested” as quickly by increasing pH. Is this LDI caused by the larger droplets leaving the PTZ of the LP Steam Turbine? Depth of damage into ACC tube?


FFS appears to arrest FAC/Corrosion in the two-phase environments of an ACC.

Much care is required when using FFS for possible problems in remainder of plant (boiler/HRSG tube failures, deposits, drums, valves, etc). Problems observed in the wide range of FFS supplied (FFA and FFP).


32

Summary


- **Some aspects relate to (LT Two-phase) FAC**
 - Adjacent black and white areas in severe turbulent areas
 - Increasing local pH reduces damage
- **But some aspects don't** (normal FAC scalloped appearance and white areas on cross members is probably LDI)
- **Environment is known and has been measured**
 - Two-phase mixture formed in PTZ of the steam turbine
 - Concentrating liquids (Higher in chloride/sulphate, organics)
 - Lower in pH (0.5) and very low in dissolved oxygen (close to zero)
- **“Arrested” two-phase FAC areas turn red slowly**
 - ACC Mechanism is thus not totally understood & what are amines/FFS doing?
 - Red coloration is known to form during shutdown
- **Results from a number of plants indicate increased Al levels in turbine and drum deposits**
 - This may result from initial operation



Air Cooled Condenser Users Group



33




IAPWS Technical Guidance Documents for Combined Cycle Plants & with ACC

- **Procedures for the Measurement of Carryover of Boiler Water and Steam (September 2008)**. This document includes the procedures to measure carryover from drum boilers to assist in preventing steam turbine failure/damage. TGD1-08
- **Instrumentation for monitoring and control of cycle chemistry for the steam-water circuits of fossil-fired and combined-cycle power plants (June 2024)**. This document includes a table that can be used to determine the minimum key level of instrumentation required for any fossil or combined cycle/HRSG plant. Also addresses fast and/or frequently started units. TGD2-09(2024)
- **Volatile treatments for the steam-water circuits of fossil and combined cycle / HRSG power plants (July 2015)**. This document includes the basis for AVT and OT for all plants with customization for plants with ACC and using ammonia and amines. Recently added guidance for fast and/or frequently started units. TGD3-10(2015)

Freely available and downloadable on IAPWS website www.IAPWS.org

34




IAPWS Technical Guidance Documents Combined Cycle Plants & with ACC

- **Phosphate and NaOH treatments for the steam-water circuits of fossil and combined cycle / HRSG power plants (Oct 2015)**. This document includes the basis for selecting the optimum boiler/HRSG evaporator water treatment for (phosphate and NaOH treatments) for all plants with drum units. TGD4-11(2015)
- **Steam Purity for Turbine Operation (Sept 2013)**. This document covers guidance for a wide range of turbines (fossil, nuclear, industrial, geothermal, etc) and failure mechanisms. It includes customizations for plants using amines and with carbon dioxide. TGD5-13
- **Corrosion Product Sampling and Analysis (May 2014)**. This document covers the optimum procedures and techniques for monitoring iron and copper. Includes a table of achievable iron levels for plants including those with ACC. TGD6-13(2014)

Freely available and downloadable on IAPWS website www.IAPWS.org

35



IAPWS Technical Guidance Documents Combined Cycle Plants & with ACC

- **HRSG HP Evaporator Sampling for Internal Deposit Identification (Sept 2016)**. This document includes the locations where to take samples from HGP and VGP HRSGs, how to analyze the samples, and an IAPWS map to assist in determining whether the HRSG HP evaporator needs to be chemically cleaned. TGD7-16
- **Application of FFS in Fossil, Combined Cycle and Biomass Plants (Revision October 2019)**. This document covers optimum application guidance for FFA / FFAP / FFP in all-ferrous plants. It also includes customizations for shutdown / layup, multiple pressures, mixed-metallurgy feedwater systems, condensate polishing, and units with ACC. TGD8-16(2019)
- **Air In-leakage (Sept 2018)**. This document covers guidance for the monitoring and control of ALL for a wide range of fossil, biomass, nuclear, and industrial plants including those with ACC. The major performance and cycle chemistry aspects are included. TGD9-18

Freely available and downloadable on IAPWS website www.IAPWS.org

36

IAPWS Technical Guidance Documents Combined Cycle Plants & with ACC

- **Application of FFS in Industrial Steam Generators (October 2019).** This document covers optimum application guidance for FFA / FFAP / FFP in industrial plants. It also includes customizations for shutdown / layup, multiple pressures, mixed-metallurgy and aluminum feedwater systems, condensate polishing, units with ACC, special boiler types and with poor makeup. **TGD11-19**
- **Chemistry Management in Generator Water Cooling (October 2019).** This document covers guidance for all generators with water-cooled windings. The high - and low - oxygen chemistries for operation and shutdown are included. **TGD10-19**

Freely available and downloadable on IAPWS website www.IAPWS.org

37



Resources for all areas of water and steam

Freely available and downloadable on IAPWS website

- www.IAPWS.org

Please give full attribution to IAPWS

38